



INSTALLATION MANUAL

for KLINGER® gaskets



INSTALLATION TIPS FOR KLINGER[®] GASKETS



INSTALLATION INSTRUCTIONS FOR KLINGER[®] GASKETS

STORAGE

1. | GASKET | DIMENSIONS



1.1 CORRECT SIZE

 \checkmark The gasket has to have the correct size.

1.2 BOLT HOLES

✓ Cut the bolt holes just a bit larger than the bolts to simplify the centralization of the gasket.

1.3 INNER DIAMETER


The inner diameter of the gasket should not be smaller than the inner diameter of the flange.



2.1 IDEAL STORAGE CONDITIONS

- ✓ The gasket should be stored horizontal to avoid tensions and permanent warpage.
- ✓ Ideal storage conditions are: » temperature < 25°C</p>
 - » air humidity 50 60%
 - » darkened storage room
 - » Store the gasket in a clean condition (ideally in a plastic bag).

3. | HANDLING



3.1 PROTECT THE GASKET

- ✓ All types of gaskets (metallic gaskets, PTFE gaskets, fibre reinforced gaskets etc.) should be handled with the same care and attention.
- ✓ Avoid carrying small gaskets in a pocket to protect the gasket from damage.
- ✓ Carry ready cutted gaskets carefully, ideally in some form of protective cover.

3.2 PROTECT THE SURFACE

X Do not bend the gasket and do not damage the surface.

3.3 TAKE CARE

✓ Metal reinforced gaskets could cause injuries.



4. | BOLTS / NUTS / WASHERS



4.1 BOLT PROPERTIES

- Pay attention that all bolts which are designed for the flange are installed.
- Check if the used bolts are suitable for the given operating temperatures.
- ✓ Tighten the bolts crosswise with the correct torque (calculation with KLINGER[®]expert).
- Ensure that there is no corrosion on the bolts because this can effect the function of the bolt.
- X Never re-use bolts.

4.2 NUT PROPERTIES

- ✓ Use a nut which has a specified proof load 20% higher than the ultimate strength of the fastener.
- ✓ Use standard threads, rather than fine.
- ✓ Use the correct lubricant.

4.3 WASHERS

- ✓ Use the same material for the washers and the nuts.
- ✓ Use washers to:
- » bridge slotted or oversized holes
- » even interface forces between joint components
- » reduce problems of fatigue by spreading the load placed by the fastener on the joint.

5. | GASKET INSTALLATION



5.1 THE TOOLS

- ✓ At first make sure that the following tools are available and in good condition:
- » the correct gasket chosen for the specific application
- » a calibrated torque wrench
- » a wire brush
- » lubricants for the bolts

5.2 CLEANING OF ALL FLANGE SURFACES


- ✓ Make sure that the flange surfaces are clean.
- ✓ Check the bolts and the flange surface if they are technically ok and free from any serious defects.
- ✓ Always brush in the direction of the grooves.
- ✓ To avoid damage on the flange surface please use a brass drift.



5.3 FLANGE CONDITIONS

✓ Make sure that the flanges are parallel and report all irregularities.

MAKE SURE THE GASKET IS UNDAMAGED -WHEN BRINGING THE FLANGES TOGETHER



5.4 IMPORTANT FOR THE GASKET

- \checkmark Insert the gasket carefully between the flanges.
- ✓ The gasket has to be centralized in the flange.
- Ensure that the gasket is installed in a dry state.
- ✓ It is important that the gasket is not pinched or otherwise damaged when bringing the flanges together.

5.5 LUBRICATION OF BOLTS

- ✓ Apply lubricant to the bolt and the nut threads as well as to the face of the nut to reduce friction when tightening.
- ✓ Pay attention that the lubricant does not contaminate the gasket or the flange surfaces.
- ✓ The recommended service temperature of the lubricant has to be within the process service temperature limits.







5.7 RE-TIGHTENING

- ✓ If retightening is considered necessary, this should only be done at ambient temperatures before or during the first start-up.
- X Never retighten compressed fibre gaskets at higher operating temperatures and longer operating times.




5.8 RE-USE OF GASKETS

 ✗ For safety reasons never re-use a gasket.
✓ The cost of a gasket is minimal compared with the costs which are related to a down time of the plant.



5.6 BOLT TIGHTENING

- ✓ The required torque value can be calculated with KLINGER[®]expert.
- ✓ The following 5 steps are necessary to achieve an even torque:
 - » finger tighten bolts (cross pattern)
 - » use 30% of the required torque (cross pattern)
 - » use 60% of the required torque (cross pattern)
 - » use 100% of the required torque (cross pattern)
 - » Close the torquing with two final passes in a clockwise sequence.







THE GASKET HAS TO HAVE THE CORRECT SIZE



Rich. Klinger Dichtungstechnik GmbH & Co KG Am Kanal 8-10 » A-2352 Gumpoldskirchen T +43 2252 62599 137 » F +43 2252 62599 296 marketing@klinger.co.at